

Saber Spot DTW **1 Channel Mode**

Channel	Value	Function
1	0 - 255	WHITE 0% - 100%

Saber Spot DTW **2 Channel Mode**

Channel	Value	Function
1	0 - 255	WHITE 0% - 100%
2	0 - 31	STROBING LED OFF
	32 - 63	LED ON
	64 - 95	STROBING SLOW - FAST
	96 - 127	LED ON
	128 - 159	PULSE STROBING SLOW - FAST
	160 - 191	LED ON
	192 - 223	RANDOM STROBING SLOW - FAST
	224 - 255	LED ON

Channel	Value	Function
1	0 - 255	WHITE 0% - 100%
2	0 - 255	WHITE FINE 0% - 100%
3	0 - 31 32 - 63 64 - 95 96 - 127 128 - 159 160 - 191 192 - 223 224 - 255	STROBING LED OFF LED ON STROBING SLOW - FAST LED ON PULSE STROBING SLOW - FAST LED ON RANDOM STROBING SLOW - FAST LED ON
4	0 - 20 21 - 40 41 - 60 61 - 80 81 - 100 101 - 120 121 - 255	DIMMER CURVES STANDARD STAGE TV ARCHITECTURAL THEATRE STAGE 2 DEFAULT TO UNIT SETTING