

| 3 CH | 4 CH | 4 CH | 5 CH | 6 CH | 6 CH | 7 CH | 8 CH | 8 CH | 9 CH | 11 CH | 12 CH | VALUES | FUNCTIONS |
|------|------|------|------|--------|------|------|------|-------|------|--------|-------|--|---|
| HSI | RGBW | HSI+ | RGBW | sRGBWI | RGBW | RGBW | RGBW | 16Bit | HSI | sRGBWI | RGBW | | |
| | 1 | | 1 | 2 | 1 | 1 | 1 | 1 | | 2 | 1 | 000-255 | RED 0-100% |
| | | | | | | | | 2 | | | | 000-255 | RED FINE 0-100% |
| | 2 | | 2 | 3 | 2 | 2 | 2 | 3 | | 3 | 2 | 000-255 | GREEN 0-100% |
| | | | | | | | | 4 | | | | 000-255 | GREEN FINE 0-100% |
| | 3 | | 3 | 4 | 3 | 3 | 3 | 5 | | 4 | 3 | 000-255 | BLUE 0-100% |
| | | | | | | | | 6 | | | | 000-255 | BLUE FINE 0-100% |
| | 4 | | 4 | 5 | 4 | 4 | 4 | 7 | | 5 | 4 | 000-255 | WHITE 0-100% |
| | | | | | | | | 8 | | | | 000-255 | WHITE FINE 0-100% |
| | | | | | | | | | | | | 000-031 032-063 064-095 096-127 128-159 160-191 192-223 224-255 | SHUTTER & STROBING LED OFF LED ON STROBING SLOW-FAST LED ON PULSE STROBING SLOW-FAST LED ON RANDOM STROBING SLOW-FAST LED ON |
| 1 | | 1 | | | | | | | 2 | | | 000-255 | HUE 0-100% |
| 2 | | 2 | | | | | | | 3 | | | 000-255 | SATURATION 0-100% |
| | | | 5 | | 5 | 6 | 6 | | | | 7 | 000-255 | MASTER DIMMER 0-100% |
| | | | | | 6 | 7 | 7 | | | | 8 | 000-255 | DIMMER FINE 0-100% |
| 3 | | 3 | | 6 | | | | | 4 | 6 | | 000-255 | INTENSITY 0-100% |
| | | | | | | | | | 5 | 7 | 5 | 000-255 | COLOR MACROS PLEASE SEE THE COLOR MACRO CHART ON PAGES 13-14 |

| 3 CH | 4 CH | 4 CH | 5 CH | 6 CH | 6 CH | 7 CH | 8 CH | 8 CH | 9 CH | 11 CH | 12 CH | VALUES | FUNCTIONS |
|------|------|------|------|--------|------|------|------|-------|------|--------|-------|---|--|
| HSI | RGBW | HSI+ | RGBW | sRGBWI | RGBW | RGBW | RGBW | 16Bit | HSI | sRGBWI | RGBW | | |
| | | | | | | | | | 6 | 8 | 9 | 000 001-020 021-040 041-060 061-080 081-100 101-120 121-140 141-160 161-180 181-200 201-220 221-240 241-250 251-255 | AUTO PROGRAMS OFF AUTO PROGRAM 1 AUTO PROGRAM 2 AUTO PROGRAM 3 AUTO PROGRAM 4 AUTO PROGRAM 5 AUTO PROGRAM 6 AUTO PROGRAM 7 AUTO PROGRAM 8 AUTO PROGRAM 9 AUTO PROGRAM 10 AUTO PROGRAM 11 AUTO PROGRAM 12 AUTO PROGRAM 13 GRADIENT EFFECT |
| | | | | | | | | | 7 | 9 | 10 | 000-255 | AUTO PROGRAM SPEED SLOW-FAST |
| | | | | | | | | | 8 | 10 | 11 | 000-255 | AUTO PROGRAM FADE SPEED FAST-SLOW |
| | | 4 | | | | 8 | | | 9 | 11 | 12 | 000-020 021-040 041-060 061-080 081-100 101-255 | DIMMER CURVES STANDARD STAGE TV ARCHITECTURAL THEATRE DEFAULT TO UNIT SETTING |